



Installation Guide

Dishwasher

SDW60B10

Congratulations on the purchase of your new Sandstrøm Dishwasher.

This is an Installation Guide for 60 cm wide freestanding dishwasher. To avoid the risk of accidents or damage to the dishwasher, it is essential to read the the instruction manual before it is installed or used for the first time.

Please follow this guide for a successful installation.

- 1. Remove all packaging before positioning the machine. (Fig 1)
- 2. Please ensure the dishwasher is installed by a qualified technician. Refer to the tools required in Fig 2.
- 3. Ensure there is clearance each side of the unit to allow slight sideways movement for servicing when required. Good levelling is essential for correct closure and sealing of the door. When the unit is correctly levelled, the door should not catch the inner liner on either side of the cabinet. The adjustable feet may be loosened or tightened in order to obtain the optimum leveling of the unit. (Fig 3)
- 4. If required, the worktop of the dishwasher can be removed. The height without the worktop is 820 mm.
 - Figure 3 outlines the minimum dimensions required to accommodate the dishwasher within fitted kitchen furniture
 - Do not connect the unit to the mains before installation. Ensure you are not installing the unit right in front of the mains. This is to avoid potential damage to the back of the unit. (Fig 4)
- 5. The condensation strip must be fitted to the underside of the worktop above your dishwasher to protect it against any moisture. Its purpose is to protect your worktop's underside from steam rising from the dishwasher. (Fig 5 and 6)
- Ensure the surface is clean prior to sticking the condensation strip to the underside of the worktop.
- Remove the backing paper from the condensation strip. (Fig 5)
- Stick the condensation strip to the underside of the worktop. (Fig 6)

NOTE: FAILURE TO ATTACH THE CONDENSATION STRIP COULD RESULT IN DAMAGE TO THE UNDERSIDE OF YOUR WORKTOP!

- 6. The worktop can be removed by removing the fixing screws located at the rear of the dishwasher (Fig 7). After removing the screws, lift and push the worktop forward to release the lugs from the front section of the dishwasher. The polystyrene block and the lugs should be saved for future use.
- 7. Position the dishwasher next to a water tap and a drain. Ensure the water inlet and drain hoses are not kinked or squashed. The unit must not stand on the mains cable. (Fig 8)
- 8. Make sure your plumbing is suitable for use with the dishwasher. If in doubt contact a qualified plumber.
 - This unit MUST BE connected to COLD WATER MAINS using the new water inlet hose. OLD HOSE SETS MUST NOT BE RE-USED. The water pressure from the water mains needs to be at a minimum of 0.04 MPa and a maximum of 1.00MPa.
 - · Connect one end of the safety water supply hose to your dishwasher, and then connect the other end of the hose to your water mains (Fig A). Please ensure the black rubber seal is in place.
 - After connecting the hose, turn on your water mains and check for
 - · Connect the dishwasher to the mains socket.
- NOTE: YOU MAY USE A Y-ADAPTOR (NOT INCLUDED) FOR ADDITIONAL WATER FEED FOR ANOTHER APPLIANCE, FOR INSTANCE A WASHING MACHINE. THIS IS ONLY APPLICABLE FOR COLD WATER MAINS. A Y-ADAPTOR IS AVAILABLE FROM MOST DIY STORES. (Fig A)
- Do not bend your drain hose. (Fig B)
- You may use the U-shaped drain hose holder to secure your drain hose and to avoid bending it. (Fig C)
- Secure the water drain hose to the waste pipe to avoid it coming off during the washing process. (Fig 9 and D)
- NOTE: THE WASTE PIPE MUST ONLY BE CONNECTED TO THE FOUL DRAINS AND NOT THE SURFACE WATER DRAINAGE SYSTEM.

THE WATER DRAIN HOSE SHOULD BE PLACED BETWEEN 40 CM AND 100 CM FROM THE FLOOR LEVEL AND MUST NOT BE EXTENDED, OTHERWISE THE UNIT MAY NOT BE ABLE TO EXPEL THE WASTE WATER PROPERLY.

Well done, your new Dishwasher is now ready to use.

You will find that there are many exciting features available. To get to know all these features, please take some time to read the instruction manual provided with your dishwasher.















































